```
// Harris Christiansen
// Created March 2014
// Team 3245
// HarrisChristiansen.com
package edu.frc.team3245;
import edu.wpi.first.wpilibj.*;
import edu.wpi.first.wpilibj.smartdashboard.SmartDashboard;
public class CompBot14 extends IterativeRobot {
  // Pilot Controls
  int leftStick=2, rightStick=4, fastBtn=8, slowBtn=7, lowGearBtn=5, highGearBtn=6;
  // Co Pilot Controls
  int togCompBtn=10, suckBtn=7, shootBtn=8, loadBtn=6, spitBtn=5, floorOutBtn=4,
floorInBtn=2, spdUpBtn=3, spdDnBtn=1;
  // Motors
  private Talon leftMotor1, leftMotor2, leftMotor3, rightMotor1, rightMotor2, rightMotor3,
shootMotor1, shootMotor2, floorMotor;
  // Current Motor Speeds
  private double leftSpeed, rightSpeed, shootSpeed1, shootSpeed2, floorSpeed;
  private double shooterSpeed=0.60;
  // Controllers
  Joystick pilotStick, coPilotStick;
  // Compressor
  Compressor mainComp;
  // Solenoids
  Solenoid driveHighSole, driveLowSole, floorOutSole, floorInSole;
  public void robotInit() {
     // Motors
     rightMotor1 = new Talon(4); // 4
     rightMotor2 = new Talon(5); // 5
     rightMotor3 = new Talon(6); //6
     leftMotor1 = new Talon(1); //1
     leftMotor2 = new Talon(2); //2
     leftMotor3 = new Talon(3); // 3
     shootMotor1 = new Talon(9); // 9
     shootMotor2 = new Talon(10); // 10
     floorMotor = new Talon(7); // 7
     // Joysticks
     pilotStick = new Joystick(1);
     coPilotStick = new Joystick(2);
```

```
// Compressor
  mainComp = new Compressor(14,1);
  // Solenoids
  driveLowSole = new Solenoid(1,1);
  driveHighSole = new Solenoid(1,3);
  floorOutSole = new Solenoid(1,5);
  floorInSole = new Solenoid(1,7);
  // Zero Motor Speeds
  zeroMotorSpeeds();
}
private int autoConfig=0;
private boolean driveCopilot = false;
public void disabledPeriodic() {
  if(DriverStation.getInstance().getDigitalIn(1)) {
     autoConfig=1;
  else if(DriverStation.getInstance().getDigitalIn(2)) {
     autoConfig=2;
  else if(DriverStation.getInstance().getDigitalIn(3)) {
     autoConfig=3;
  driveCopilot = DriverStation.getInstance().getDigitalIn(4);
private int autoCount=0;
public void autonomousInit() {
  zeroMotorSpeeds();
  shooterSpeed=0.645;
  autoCount=0;
}
public void autonomousPeriodic() {
  if(autoConfig==1) {
     zeroBallAuto();
  } else if(autoConfig==2) {
    oneBallAuto();
  } else if(autoConfig==3) {
    twoBallAuto();
  }
}
public void oneBallAuto() { // Drive and Shoot
  autoCount++;
  if(autoCount>=0&&autoCount<=75) {
     shootSpeed1=1.0;
     shootSpeed2=1.0;
```

```
leftSpeed=-0.35;
    rightSpeed=-0.375;
  else if (autoCount>75&&autoCount<=270) {
    shootSpeed1=shooterSpeed;
    shootSpeed2=shooterSpeed;
    leftSpeed=0.0;
    rightSpeed=0.0;
  else if (autoCount>270&&autoCount<=330) {
    shootSpeed1=shooterSpeed;
    shootSpeed2=shooterSpeed;
    floorSpeed=0.65;
    leftSpeed=0.0;
    rightSpeed=0.0;
  } else {
    shootSpeed1=0.0;
    shootSpeed2=0.0;
    floorSpeed=0.0;
    leftSpeed=0.0;
    rightSpeed=0.0;
    if(autoCount==340) { mainComp.start(); }
  updateMotors();
}
public void zeroBallAuto() { // Just Drive
  autoCount++;
  if(autoCount>=0&&autoCount<=100) {
    leftSpeed=-0.4;
    rightSpeed=-0.4;
  } else {
    leftSpeed=0.0;
    rightSpeed=0.0;
  updateMotors();
}
public void twoBallAuto() { // 2 Ball - Shoot Drive Shoot
  autoCount++;
  if (autoCount>0&&autoCount<=50) {
    shootSpeed1=1.0;
    shootSpeed2=1.0;
    floorSpeed=0.0;
    leftSpeed=0.0;
    rightSpeed=0.0;
  } else if (autoCount>50&&autoCount<=100) {
    shootSpeed1=0.712;
```

```
shootSpeed2=0.712;
  floorSpeed=0.0;
  leftSpeed=0.0;
  rightSpeed=0.0;
} else if (autoCount>100&&autoCount<=130) {
  shootSpeed1=0.712;
  shootSpeed2=0.712;
  floorSpeed=0.65;
  leftSpeed=0.0;
  rightSpeed=0.0;
} else if (autoCount>130&&autoCount<=200) { // Floor Out
  shootSpeed1=0.0;
  shootSpeed2=0.0;
  floorSpeed=0.65;
  leftSpeed=0.0:
  rightSpeed=0.0;
  floorOutSole.set(false):
  floorInSole.set(true);
} else if (autoCount>200&&autoCount<=210) { // Floor In
  shootSpeed1=0.0;
  shootSpeed2=0.0;
  floorSpeed=0.45;
  leftSpeed=0.0;
  rightSpeed=0.0;
  floorOutSole.set(true);
  floorInSole.set(false):
} else if (autoCount>210&&autoCount<=220) {
  shootSpeed1=1.0;
  shootSpeed2=1.0;
  leftSpeed=-0.35;
  rightSpeed=-0.375;
  floorSpeed=-0.45;
  floorOutSole.set(false);
  floorInSole.set(false);
} else if (autoCount>220&&autoCount<=230) {
  shootSpeed1=1.0;
  shootSpeed2=1.0;
  leftSpeed=-0.35;
  rightSpeed=-0.375;
  floorSpeed=-0.4;
} else if (autoCount>230&&autoCount<=285) {
  shootSpeed1=1.0;
  shootSpeed2=1.0;
  leftSpeed=-0.35;
  rightSpeed=-0.375;
  floorSpeed=0.0;
} else if (autoCount>285&&autoCount<=420) {
  shootSpeed1=shooterSpeed;
  shootSpeed2=shooterSpeed;
```

```
leftSpeed=0.0;
    rightSpeed=0.0;
    floorSpeed=0.0;
  } else if (autoCount>420&&autoCount<=480) {
    shootSpeed1=shooterSpeed;
    shootSpeed2=shooterSpeed;
    leftSpeed=0.0;
    rightSpeed=0.0;
    floorSpeed=0.65;
  } else {
    shootSpeed1=0.0;
    shootSpeed2=0.0;
    floorSpeed=0.0;
    leftSpeed=0.0;
    rightSpeed=0.0;
    if(autoCount==490) { mainComp.start(); }
  updateMotors();
}
public void teleopInit() {
  zeroMotorSpeeds();
  shooterSpeed=0.66;
  // Start Compressor
  mainComp.start();
}
public void teleopPeriodic() {
  updateTankDrive();
  updateDriveShifter();
  updateShooter();
  updateFloorLoader();
  updateToggleComp();
  updateMotors();
}
public void testInit() {
public void testPeriodic() {
}
// Custom Functions
public void zeroMotorSpeeds() {
  leftSpeed=0.0;
  rightSpeed=0.0;
  shootSpeed1=0.0;
  shootSpeed2=0.0;
  floorSpeed=0.0;
}
```

```
public void updateTankDrive() {
  double drivePercent = 0.55;
  if(pilotStick.getRawButton(fastBtn)) { drivePercent=1.00; }
  else if(pilotStick.getRawButton(slowBtn)) { drivePercent=0.30; }
  leftSpeed=pilotStick.getRawAxis(leftStick)*drivePercent;
  rightSpeed=pilotStick.getRawAxis(rightStick)*drivePercent;
  if(driveCopilot) {
     leftSpeed=coPilotStick.getRawAxis(leftStick)*drivePercent;
     rightSpeed=coPilotStick.getRawAxis(rightStick)*drivePercent;
  }
}
public void updateDriveShifter() {
  if(pilotStick.getRawButton(lowGearBtn)) {
     driveLowSole.set(true):
     driveHighSole.set(false);
  } else if(pilotStick.getRawButton(highGearBtn)) {
     driveLowSole.set(false);
     driveHighSole.set(true);
  } else {
     driveLowSole.set(false);
     driveHighSole.set(false);
  }
}
public boolean spdCnqd=false:
public int shootCount=0;
public void updateShooter() {
  if(coPilotStick.getRawButton(shootBtn)) {
     shootCount++;
     if(shootCount<60) {
       shootSpeed1=1.0;
       shootSpeed2=1.0;
    } else {
       shootSpeed1=shooterSpeed+0.1;
       shootSpeed2=shooterSpeed-0.1;
     if(mainComp.enabled()) { // FOR TOMORROW - Test If Working
       mainComp.stop();
  else if(coPilotStick.getRawButton(suckBtn)) { shootSpeed1=-0.41; shootSpeed2=-0.41; }
  else {
     shootCount=0;
     if(!mainComp.enabled()&&shootSpeed1!=0.0) { // FOR TOMORROW - Test If Working
       mainComp.start();
     shootSpeed1=0.0;
     shootSpeed2=0.0;
```

```
if(coPilotStick.getRawButton(spdUpBtn)&&!spdCngd) { spdCngd=true:
shooterSpeed=shooterSpeed+0.005; System.out.println(shooterSpeed); }
     else if(coPilotStick.getRawButton(spdDnBtn)&&!spdCngd) { spdCngd=true;
shooterSpeed=shooterSpeed-0.005; System.out.println(shooterSpeed); }
     if(!coPilotStick.getRawButton(spdUpBtn)&&!coPilotStick.getRawButton(spdDnBtn))
{ spdCnqd=false; }
     SmartDashboard.putNumber("Shooter Speed", shooterSpeed);
  }
  public void updateFloorLoader() {
     if(coPilotStick.getRawButton(loadBtn)) { floorSpeed=0.8; } // 65
     else if(coPilotStick.getRawButton(spitBtn)) { floorSpeed=-0.8; }
     else { floorSpeed=0.0; }
     if(coPilotStick.getRawButton(floorOutBtn)) {
       floorOutSole.set(true);
       floorInSole.set(false);
     } else if(coPilotStick.getRawButton(floorInBtn)) {
       floorOutSole.set(false);
       floorInSole.set(true);
    } else {
       floorOutSole.set(false);
       floorInSole.set(false);
    }
  }
  boolean togCompSwitched=false;
  public void updateToggleComp() { // FOR TOMORROW - test if working
     if(coPilotStick.getRawButton(togCompBtn)&&!togCompSwitched) {
       togCompSwitched=true;
       if(mainComp.enabled()) {
         mainComp.stop();
       } else {
         mainComp.start();
     } else {
       togCompSwitched=false;
  }
  public void updateMotors() {
     double correction = 11.2/DriverStation.getInstance().getBatteryVoltage();
     if(DriverStation.getInstance().getBatteryVoltage()<8.00) {
       correction = 1.00;
     }
     leftMotor1.set(leftSpeed*correction);
     leftMotor2.set(leftSpeed*correction);
     leftMotor3.set(leftSpeed*correction);
```

```
rightMotor1.set(-rightSpeed*correction);
rightMotor2.set(-rightSpeed*correction);
rightMotor3.set(-rightSpeed*correction);
shootMotor1.set((-shootSpeed1*correction));
shootMotor2.set((-shootSpeed2*correction));
SmartDashboard.putNumber("Shooter Voltage",
shooterSpeed*correction*DriverStation.getInstance().getBatteryVoltage());
floorMotor.set(floorSpeed*correction);
}
}
```